NO Pre-asembled Pigtail, you should make a fiber fusion.

The Splice Box is used to fusing the fiber ends inside the splices box.

