


# Installation Guide Panel Accessory Plastic Box

# **Installation Holes Map**



**Note**: This box is only suitable for devices powered by voltages below 60VDC or 42.4VAC.

# **Installation of Accessories** (Maximum of 2)

**ProSYS 8 Zone Expansion Module** 


**ProSYS 4 Relay Output Module** 

**ProSYS 8 O.C. Output Module** 

**ProSYS Event Log Expansion Module (512, 999)** 


**ProSYS X-10 Expansion Module** 

Connection holes: 1, 2, 13, 14 and/or 3, 4, 15, 16



# Installation of a single 16 Zone Expander

Connection holes: 7, 10, 17, 18




# **Installation of GT Accessories** (Maximum of 2)

Zone Expander (Code 02083)

Relay Output Expander (Code 02085)

ID Expander (Code 02087)

Connection holes: 5, 8, 11 and/or 6, 9, 12



## **Technical Specifications:**

Dimensions: 192 mm x 150 mm x 57 mm

### Certification:

EN50131-3 Grade 3 Environmental class II

### Ordering Information:

Model	Description
ProSYS B5	Plastic accessory box with tamper

## **RTTE Compliance Statement:**

Hereby, RISCO Group declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For the CE Declaration of Conformity please refer to our

website: www.riscogroup.com.



© RISCO Group 08/2016

5IN1151 D